

## **Firmware Installation Instructions**

To install a firmware update for the Fermostat:

- Download the latest Fermostat firmware version from the Downloads section of the [Support](#) page on the Ohmbrew Automations website.
- Unzip the downloaded .zip file and copy the contents to the root directory (not under any folders) of a micro SD ( $\mu$ SD) card\*\*.
- Insert the  $\mu$ SD card into the top side of the Fermostat (press in until it clicks, which is pretty far, a thumbnail or penny might be required to completely seat it).
- Recycle the power on the Fermostat. The blue LED should start quickly flashing after 5-10 seconds, which means it is installing the update.

The update will take around 4 minutes to complete. Do not remove power from the Fermostat during the update. Once finished, the blue LED will stop blinking and the Fermostat will boot normally.

Verify that update was successfully installed by going to the menu of the Fermostat. Once in the menu, go to the 'Settings' menu, then select 'About'. The SW version should reflect the version that you just installed and downloaded.

*\*\*  $\mu$ SD Card should be formatted with a FAT32 file system.*

*If you have any questions or problems, please check out the Ohmbrew Automations FAQ or the forum.*

*You can also send email to: [support@ohmbrewautomations.com](mailto:support@ohmbrewautomations.com)*